
Android Platform to introduce and use of guidance

Acegame S.A

Mobile Phone

Zen Element 2nd Gen

CONTENTS

How Introduction	- 5 -
Introduction phone keys	- 5 -
Introduction widgets	- 5 -
Information Function	- 6 -
Emoji Keyboard.....	-9-
Contact Features	- 11 -
Call History Features	- 13 -
Dail and caller ID display.....	-12-
Paste the text / copy Features.....	- 14 -
E-mail Features	- 16 -
Desktop Features	- 18 -
New lock screen and color schemes.....	-16-
Wallpapers	-17-
Application packet	- 18 -
Full Screen Function	-19-
Wireless Printing Function	-20-
Bluetooth Function	- 22 -
Wifi Features	- 24 -
Flight mode Function	- 24 -
Black unlock	- 26 -
Restore to factory default	- 27 -
Storage Settings	- 27 -
GPS Settings.....	- 28 -
English language switching phone	- 28 -
Replacement mobile phone input method	- 29 -
Android phone data cable links	- 30 -
Introduce cross-screen display.....	- 31 -
Browser Features	- 31 -
Q/A	- 33 -
1. How to turn off the software running in the background too much.....	- 33 -
2. How to quickly set up Email	- 33 -
3. How do I view the capacity of SD card case.....	- 34 -
4. How to save electricity Andy 5EI	- 34 -
5. How Andy 5EI lock screen, to prevent others from using	- 34 -
6. Why does not the USB data cable links your computer	- 34 -
7. How to install a program on a non-Android Market	- 34 -
8. In browsing the web or other applications, how to switch to other applications-	34 -
9. How to enter the silent mode quickly	- 34 -
10. How to forward SMS / MMS.....	- 34 -

11. how to paste and copy text.....	- 35 -
12. In the phone program group is installed too many applications, how to solve- 35 -	
13. Contacts are sorted, can change	- 35 -
14. Contacts whether to support the group	- 35 -
15. contacts and SMS storage capacity limits the number of	- 35 -
16. How to set the SD card, personalized ring tones.....	- 35 -
17. How to sync the phone contacts to the original Andy 5EI	- 35 -
18. How to use the Andy 5EI access Wifi (WLAN).....	- 35 -
19. How to Find Contact.....	- 35 -
20. how to download applications for the Andy 5EI	- 35 -
21. What are commonly used android forum	- 36 -
22. How do I delete the downloaded software	- 36 -
23. How to view mobile phone version information.....	- 36 -
24. How do I copy SIM card contact information	- 36 -
25. why the message has a different time and date display	- 36 -
26.Andy 5EI whether to support the Java....	- 36 -
27.How to open developer options	- 36 -

Basic terms

Root: Super Android system is the administrator user account, which has the authority to control the whole system, and only have the privileges to the original system can be refreshed for the revision of the various systems;

APK: Android application types, with the cab and the Windows Mobile platform, like exe files, the user can be installed directly;

Eclari : The name of one of the Android platform, version, and the corresponding version number is 5.0, omega use this version;

Webkit: Core Android platform, browser, and now Apple's Safari, Google's Chrome and FireFox are using this kernel as a web page rendering mechanism;

GPhone: To use Google Android mobile phone operating system developed collectively, omega, etc.;

ActiveSync: Push email solution to support Microsoft proprietary technology, pre-primary mailbox servers at Microsoft (Exchange server) to provide support, and now Google's Gmail also provided support

How Introduction

Introduction phone keys

Menu button: Click on the program display the corresponding menu item, the user can choose the corresponding sub-menu functions;

Home button: Click on the background into the current application will, and enter the main interface; Note that using this key will not really exit the application, the application will continue to run in the background;


Back button: Click to fall back to previous step of the operation of the interface;

Introduction widgets

1, long press the space of the idle -choose widgets,add widgets to the main screen: in the widgets interface - > Long press a widget can add to the main screen


2, change the position of widgets: in the main interface, Long press a widget, sliding the widget can change the position of the widget in the main screen

3. Delete widgets: in the main interface, Long press a widget, the top of the main screen will be delete ", sliding the widget to delete , when there is red ", can let go, the widget is deleted




Information Function


To sort the information by contacts, the conversational arrangement, user understanding of the history of the entire communication information, information sorted according to first contacts, including contact name for the first numbers, then letters (A-Z)



Send MMS


New information -"click  , add "function - " to select the desired additional content;

New information-click the menu button -add theme





Replacement SMS reminder tone


Access to the information interface - "click the menu button, select "Settings
"function ,select "Notifications "function ,Then select “sound.




View the sender information

Access to the information screen - "Select the message - " click


 - "click  ,can view the sender information"- "click

 ,can add to favorites".




Forwards

Access to the information screen - "Select the message - "short press the message can display the message details" -Long press the Information, there shortcut keys - "select"Forward "function





View information details

Access to the information screen- "Select the message-" Long press the Information, there shortcut keys -"select View details "function




Access to the information screen - "Select the message - " Long press and Information, there shortcut keys - "select "Delete "function



Emoji Keyboard

Support rich interesting Emoji input, and it can make your message more personal.




Contact Features

contacts groups, contacts and favorites feature;


Book description

By the first number, then sort the way English characters (A-Z)



Favorites Introduction:


Included collection of contacts, and users often call the recent contact information, part of the overall fabric Top of the contact information for the user collection, lower often call into the system default contact information;



Contact Search

Into the contact interface - "click  button


Search supported by the first letter and the entire search string





Import contact information methods
using Bluetooth to achieve data synchronization
MMX phone and the original binding, using Bluetooth to achieve
synchronization of contacts;

Call History Features


One by one to delete call records

Enter the call log interface - "Click the menu button –Select the delete
Function- " Choose the delete call records- click ok button-"Click 


choose the resources of the sim card"



Contact information stored call records


Enter the call log screen - "Select the Save call log - " click- "select "Add to
Contacts "feature Or directly into the call log entry, -click  button -select

"Add to Contacts "feature.




Dial and caller ID display Features

New dial-up procedures will be according to your habits, automatic intelligent recommend commonly used contact, convenient to speed dial, Some well-known enterprises or service of the number of the caller, using Google's online database for matching automatically display name.



Paste the text / copy Features

Into the input field - "input string, long press and enter the region, there shortcut keys - " select All " " cut All " ,"copy All", "paste All"



E-mail Features

Configuring mail account

Enter the Program Group screen - "Select"Email"application -"Enter e-mail address and password

If the system automatically recognizes the mailbox information, will automatically configure; if the system does not recognize, will require users to type IMAP mailbox, or POP3, enter the appropriate configuration information.


For example:

E-mail Address: 936877975@qq.com

Password:


Configure multiple email accounts

Enter the Program Group screen - "Select"Email"application -" Click on the menu button-select setting function -select "Add Account"feature




Delete email account

Enter the Program Group screen - Select"Settings" - Click "Accounts"-Then Click "IMAP",enter the account you log in.then remove account.



Email check frequency setting

Enter the Program Group screen - Select "Settings" application - Click on the menu button-select setting function –select account - " select I box check frequency "function




Desktop Features

The common features into the desktop


Interface into the program group - "Select the desktop into the application

-"long by application, the application will be placed to the desktop;




New lock screen and color schemes Function

Blue/green color design has changed into white/gray, more simple, the other ICONS style also further flattening, Also joined the translucent interface style, to ensure the status bar and the navigation bar can play better effect in application.




Wallpapers

In the desktop space - the "long Click the desktop, the shortcut keys
-"Select"Wallpaper"feature.




Application Packet

In the desktop space – sliding the application to another application – click the application to open New Folder




Change the folder name

Open the folder on the desktop - " click Input box - Rename Folder





Add contacts to your desktop

In the widgets space -long press the contact widget -" choose a contact .for example the contact "Amma".



Add URL to the desktop

In the widgets space -long press the Bookmark widget -" choose a bookmark



Add a playlist to your desktop


In the widgets space -long press the Music playlist widget -" Select a playlist
(operation method and procedure as above)

Delete the contents of the desktop

Select the desktop content - then "Long press the icon - " into the remove icon
to the lower right corner of the screen



Full Screen Function

Whether you are looking at the books, or use any application, you can easily
into the full screen mode





Wireless Printing Function

You can use Google Cloud Print to Print the photos, documents, or web pages.”gallery-choose one picture -menu-print-set a google account -choose print /save as PDF”




Bluetooth Function

Select "Settings" -> Select "Bluetooth" function




Wifi Features

Select "Settings"->"Select Wi-Fi"- select "Add Network ", select the desired access APN




Flight mode Function

Select "Settings"->"Select More"- choose "Airplane Mode"function




Or select the phone, "Off"button - "select the"Flight Mode "function




Black unlock

Select "Settings"->"Select " security "-> Select the " Screen lock"-Pattern.




Restore to factory default

Select "Settings"->"Select"Backup&reset "-> select "Factory data reset"




Storage Settings

Select "Settings"->"Select"storage"





GPS Settings

Select "Settings"- "Select " location"





English language switching phone

Select "Settings"- "Language & input "- Select " Language ", select English or other




Input set

Select "Settings"- " Language & input "-click"Android Keyboard Settings" button



Replacement mobile phone input method


Select "Settings"- " Language & input "- click"Swiftkey Keyboard " button



Android phone data cable links



Select "Settings"->"Select"Developer options"->"Check"USB debugging "

Products installed on your computer drive, the link on the USB cable;



Introduce cross-screen display

Select "Settings"->"Display "When device is rotated" according to the phone automatically change the direction of rotation




Browser Features

Visit the website


Browser - "Click url input area "- Enter the URL of web browsing-click



button




Download Web page images or other objects
 Browser - "browse the web, long press on the picture, there shortcut keys, choose "Save Image "function



Browser settings / search page

Browser - "browse the web" - click "menu button", - select settings / find on page



Q/A

1. How to turn off the software running in the background too much

Download Advanced Task Manager Advanced Task Manager and select install, it can help you achieve, automatic end of the program services, to switch between programs, display memory information, exclusion list, an end of all widgets, fast uninstall program and other functions, To free up memory space, reducing the CPU's operation long pressure, increase speed, to extend the purpose of standby time.

2. How to quickly set up Email

In the Android system, can automatically set the POP3 or IMAP e-mail most accounts, the e-mail application, directly enter the e-mail address and password, if not automatically fit in the mailbox, the mailbox will be required by

user Server information. See details in front of the "E-mail Features" section.

3. How do I view the capacity of SD card case

Select the "Settings"-Select Storage -select "SD card and phone memory", will see the current SD card capacity information phone

4. How to save electricity omega.

First, reduce the screen brightness can be used in peacetime by reducing the brightness to reduce battery consumption, in the "Settings " in the "sound and display" found on "brightness", and then sliding scale in respect of the brightness can be set Android phones;

Close GPS global positioning, in the "Settings" and select "location services" -uncheck the following "Enable GPS satellite set" can be;

Usually if you do not use the Wi-Fi, Bluetooth headset can be improved by turning off these options to the standby time, turn off the WLAN search can save about 30% to 40% of standby time;

Usually close calls and text messages to remind vibration;

5. How omega lock screen, to prevent others from using

In the "Settings", select " Security " and then select "screen lock""pattern", to set individual unlock pattern, to prevent strangers use or purpose of ensuring privacy of confidential documents.

6. Why does not the USB data cable links your computer

Confirmed in the phone's "Settings"-""Developer options"- " in the "USB debugging" functionality check; also installed the correct USB driver

7. How to install a program on a non-Android Market

Select "Settings"-"" Security ", the "unknown source "function check

8. In browsing the web or other applications, how to switch to other applications

If you need to open when browsing other applications, you can long press the Home key to achieving long task switch, long press return directly to the desktop (note that the system default task only last 6 months)

9. How to enter the silent mode quickly

Long press the power key, and directly Into the pop menu to select the silent mode.

10. How to forward SMS / MMS

Long press and Information applications in the information content of an item in the list, until the pop-up shortcut menu, select "Forward" can be realized.

11. how to paste and copy text

Into the input field - "input string, long press and enter the region, there shortcut keys - " select All " " cut All " ,"copy All","paste All"

12. In the phone program group is installed too many applications, how to solve

In the desktop space – sliding the application to another application – click the application to open New Folder

13. Contacts are sorted, can change

Sort of way platform, the first number, then letters, then the Chinese way of sorting; the user can not set their own sort

14. Contacts whether to support the group

In the contacts interface-select group

15. contacts and SMS storage capacity limits the number of

Platform reason, contacts and SMS storage for no clear limit value, depending on the size of the current mobile phone memory space

16. How to set the SD card, personalized ring tones

In the SD card, are established "ringtones" (ringtones) "alarms" (alarm tone) "notifications" (SMS notification tone), the ring tones into a different folder, the phone can be automatically identified.

17. How to sync the phone contacts to the original omega

using Bluetooth the way, the two cellphone, sync contacts;

18. How to use the omega access Wifi (WLAN)

Wifi signal at the scene to ensure that the premise of the specific see "Wifi function "

19. How to Find Contact

Into the contact interface, select the "Search"menu, you can search for contacts, you can use the first letter of query letters;

20. how to download applications for the omega

1) Visit Google Market <http://www.android.com/market/>; need to pay to download some software;

2) third-party sites, access to applications, such sites are:

<http://www.waptw.com/>

<http://android.sj.91.com/list/rjyxhj.shtml>

.....

More downloaded software will be installed in the SD card and some software may vary depending on operating system version, network access nodes, size or other reasons can not be used.

21. What are commonly used android forum

<http://www.waptw.com/>

<http://sj.91.com/>

<http://www.android123.com/>

<http://www.android86.com.cn/>

<http://www.androidin.net/bbs/index.php>

<http://bbs.zhiqi.com.cn/forum-33-1.html>

<http://www.androidin.net/bbs/>

<http://www.hiapk.com/bbs/>

22. How do I delete the downloaded software

"Settings" - ""Manage app"- "Select the application to be deleted

23. How to view mobile phone version information

"Settings" - "" About phone "mobile phone version information can be obtained, including the Android version, Linux version, software version, hardware version, etc.

24. How do I copy SIM card contact information

Into the Contacts application, click the menu button, select "Import Contacts", then you can see the SIM card contacts, if only to import one, you can click an item. If all the import needs to long press the menu key, select Import to import all.

25. why the message has a different time and date display

Message displayed on the principle that the display of the day time and date have shown that non-day

26. omega whether to support the Java

omega support Java,

27.How to open developer options

Enter the Settings -- the About phone -- click the Build number five times, system will be generated developer options

Environmental Conditions

Working Temperature -20 ~ 25°C
Working humidity 65+/-20%RH

Caution:

The AC plug considered as disconnect device of adapter.

Hereby, declares that this Mobile Phone, is In compliance with the essential Requirements and other relevant provisions of Directive 1999/5/EC.

Environment friendly disposal



You can help protect the environment!
Please remember to respect the local regulations:
hand in the non-working electrical equipments to
an appropriate waste disposal centre.

CE 0700

A warning that batteries(battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

The following standards have been applied for the investigation of compliance:

ETSI EN 301 489-1 V1.9.2: 2011
ETSI EN 301 489-3 V1.6.1: 2013
ETSI EN 301 489-7 V1.3.1: 2005
ETSI EN 301 489-17 V2.2.1: 2012
ETSI EN 301 489-24 V1.5.1: 2010
ETSI EN 301 511 V9.0.2: 2003
ETSI EN 300 440-1 V1.6.1: 2010
ETSI EN 300 440-2 V1.4.1: 2010
ETSI EN 300 328 V1.8.1: 2012
ETSI EN 301 908-1 V6.2.1: 2013
ETSI EN 301 908-2 V6.2.1: 2013
ETSI EN 301 908-13 V6.2.1: 2013
ETSI EN 301 893 V1.8.1: 2015
EN 62479: 2010

IEC 62471: 2006
EN 50566:2013
EN 50360:2001+A1:2012
EN 62209-1:2006
EN 62209-2:2010
EN 60950-1: 2006 +A11: 2009 +A1: 2010+A12:2011
EN 50332-1: 2000
EN 50332-2: 2003
EN 55022:2010
EN 55024:2010
EN 61000-3-2:2014
EN 61000-3-3:2013

Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss The product shall only be connected to a USB interface of version USB2.0 or higher and that the connection to a power USB is prohibited. Adapter shall be installed near the equipment and shall be easily accessible.

Only can use adapter as below: GT Mobile Pte Ltd



The RF distance between body and mobile phone is 15mm.

For 5150-5250 frequency band,
Operations in the 5150-5250 bands are restricted to indoor usage only.

WIFI 2.4G and 5G bands support Hotspot.

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types **Zen Element 2nd Gen (FCC ID: 2ADTU-ELEMENT)** has also been tested against this SAR limit. The highest reported SAR values for head, body-worn accessory, and product specific (Hotspot) are **0.78 W/kg, 1.34 W/kg, and 1.38 W/kg** respectively. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

5G

For 5150-5250 frequency band,

Operations in the 5150-5250 band are restricted to indoor usage only.