



EXHIBIT C - EUT INTERNAL PHOTOGRAPHS


EUT – Uncover View



EUT – Uncover View




EUT – Uncover View




EUT – Uncover View




EUT – Uncover View




EUT – Uncover View




EUT – Uncover View




EUT – Uncover View




EUT – Uncover View




EUT – Main Board Top View




EUT – Main Board Bottom View




EUT –Sub-board Top View




EUT – Sub-board Bottom View




EUT – Photosensitive Module Top View




EUT –Photosensitive Module Bottom View




EUT –Display Control Board Top View




EUT –Display Board Bottom View




EUT –Interface Board Top View




EUT –Interface Board Bottom View




EUT –Battery Connector Top View




EUT –Battery Connector Bottom View




EUT –Connector Board View




EUT –Connector Board Bottom View




EUT – RF Board Top View




EUT –RF Board Top Unshielded View




EUT –RF Board Bottom View




EUT –RF Board Bottom Unshielded View



EUT –Wifi & BT Chip View



EUT – GNSS Chip View



EUT – Antenna View



EUT – Antenna View



EUT – Antenna View



EUT –Battery Top View



EUT – Battery Bottom View



EUT –Battery Label View

