


3.4.2


Rear View



Feed the Luna Dock Main Cable through the Freestanding Base - USB or Power Cable first. Ensure the cable is orientated correctly.


3.4.3

Rear View




Feed the Luna Dock Main Cable through the Freestanding Base - USB or Power Cable first. Ensure the cable is orientated correctly.

3.4.4




Slide the Luna Dock into its locked position.

3.4.5




Tighten to: ##Nm

4.3.1 Dock/Undocking Correctly




Dock your Luna Case using both hands.

4.3.2




Undock you Luna Case using both hands.

4.3.3




Do not use one hand to Dock your Luna Case

4.3.4




Do not use one hand to Undock your Luna Case


4.2.1.1 Dock & Lock First Start up



4.2.1.2




3.4.6



Whilst holding the Freestanding Base upside down, route the Luna Dock Cable securely within the cable slot in the underside of the Freestanding Base.

3.4.7




Secure the Freestanding Security Cable to an immovable object in your installation location - such as looping around a table leg. Then attach the cable to the Freestanding base as indicated.


3.4.8



If adding multiple RFID Fobs, do not complete this stage - go to section 5.1




3.4.9




The installation of your Luna Freestanding Base is now complete. Proceed to section 3.5


3.5 Luna Case Installation



In the Case & Fixings Box




3.5.1




Place your Luna Case down (onto a soft surface to minimise risk of damage). Insert the Case Key and carefully turn anti-clockwise, whilst lifting the case until the case opens.

4.2.1 Dock & Go Setup




Set-up the DC power supply - use the appropriate plug attachment for your region.

4.2.2




4.2.3




The Dock Power Light remains on whilst the Luna Dock is powered.


4.1.3.5




4.1.3.6




4.1.3.7



4.1.3.8




3.5.2




Select the correct Tablet Support appropriate to your iPad Air model. Luna is only compatible with the Apple iPad Air 1 and Air 2.


3.5.3




3.5.4




3.5.5




3.5.6




3.5.7




3.5.8




3.5.9




4.1.3.1 Luna Dock & Lock Undocking




4.1.3.2




4.1.3.3



4.1.3.4




4.1.2.1 Luna Dock & Lock Docking




The Dock Power Light remains on whilst the Luna Dock is powered.
Refer to section 6 if this light isn't visible.

4.1.2.2




Refer to Section ## on how to correctly dock your Luna Case into the Luna Dock.

4.1.2.3




The Luna Case Status Light will flash White, and Beep twice to confirm that the Luna Case is correctly docked.

4.1.2.4




If the Case Status Light is Red and the Dock continuously beeps, remove the case and re-dock it. This occurs if the Case is not correctly Docked - the Dock will not Lock until correctly docked.

3.5.10



Ensure the Audio cable remains within the case.


3.5.11



The Luna Case Installation is now complete. Proceed to section 4


4 Product Operation

4.1.1.1 Dock & Lock First Start up



Set-up the DC power supply
- use the appropriate plug
attachment for your region.


4.1.1.2



! Your Luna Case must
not be docked.

4.1.1.3

2x Beep
White Light Flashing



Do not Dock the Luna Case whilst
the Dock Power Light is flashing -
your Luna Dock is booting up

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The distance between user and products should be no less than 20cm