

314mm



159mm

What's in the box

- 1 x Solar Audio Table Techno #0124
- 1 x Bluetooth speaker Unit
- 1 x User's manual
- 1 x AUX cable
- 1 x Remote Control
- 1 x 10V1A DC adapter and wall plug

How to Charge the "Techno 0124" (Rechargeable built-in battery)

1. Connect "Techno 0124" with the 10V USB adapter and wall plug included.
2. The Red LED will turn ON during charging and will turn OFF after charging is complete.
3. Unplug DC charger after charging is complete.

Note: Charging the rechargeable battery with Sun Light

The embedded Solar Panel will be able to charge the rechargeable battery when operating outdoors in a sunny area.

Remote Control

1. **Power on/off**
2. **Volume+** Press and Hold to turn Volume up, Short-Press to skip tracks forward
3. **Volume-** Press and Hold to turn Volume down, Short-Press to skip tracks backward
4. **Play/Pause** **Bluetooth** disconnection
Press and Hold for disconnecting the **Bluetooth**.
In Bluetooth mode first Short-Press to Play & Pause music (only in **Bluetooth** mode)
5. **LED lights** switch on /off

How to start the "Techno 0124"

Press and Hold the Power on/off button for 3 seconds on the Remote Control.

How to pair the "Techno 0124" to (Bluetooth enabled) mobile phones and Tablets.

1. Turn on the "Techno 0124", the blue & red LEDs will blink rapidly, indicating the unit is in standby mode for pairing.

How to pair "Techno 0124" with (Bluetooth enabled) mobile phones and Tablets.

2. Start the **Bluetooth** function on your mobile phone and search the **Bluetooth** devices. Select the name "Techno 0124" from your **Bluetooth** device list.
3. After pairing is successful, select the "Techno 0124" from the **Bluetooth** device list, and press "connect".
4. The LED will change to solid blue indicating a successful connecting.

Note:

1. If the pairing is not successful, power off the speaker, then power on the speaker and then re-pair once again.
2. After initial pairing success, paired devices will be stored in memory. Therefore there is no need to go through the pairing steps for future use. (Note: You will need to re-pair the device if the item is deleted from your **Bluetooth** device list).
3. If you want to pair the speaker with another device, disconnect the "Techno 0124" with existing paired device by pressing (button as shown) , the pair with a new device, following the steps 1-4 as indicated above.

How to pair "Techno 0124" with (iPhone/iPad) ®

1. Please keep (iPhone/iPad) ® and "Techno 0124" within a 1 meter (3ft) distance when pairing.
2. Turn on the "Techno 0124", the blue & red LEDs will blink rapidly, indicating the unit is in standby mode for pairing.
3. On your (iPhone/iPad) ® navigate to the following path: General > **Bluetooth**, then tap on **Bluetooth** function, and search through the **Bluetooth** devices, and select the "Techno 0124" to connect.

How to reconnect to a paired device (iPhone/iPad) ®

1. Your (iPhone/iPad) ® will connect to last connected device automatically. (the device must be powered on).
2. If the device is not re-connected automatically, then select the "Techno 0124" listed in the screen of devices on your (iPhone/iPad) ®.

How to operate the volume control

1. Control volume via the **Bluetooth** device itself.
2. Control volume via the volume +/- buttons on the Remote Control.

How to use the AUX port (for non-Bluetooth devices)

1. Using the AUX cable (included), you can connect the "Techno 0124" to the AUX port on any music device.
2. Play music through the device connected.

Note: Only the "Volume+/-" and "LED-lighting" function works in AUX mode.

How to operate the lights

Press (button as shown) on the Remote Control to turn on/off lights.

Compliance with FCC Regulations

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.

If at any time in the future you want to dispose this product, please note that electrical products should not be disposed with household waste. Find out where your nearest recycling centre is. Consult your local authority or retailer for more details (Waste Electrical and Electronic Equipment Directive).

THE SPECIFICATION AND EXTERNAL APPEARANCE OF THE SET ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.



Contenu

- 1 x Table audio à énergie solaire Techno #0124 **Bluetooth**
- 1 x Manuel de l'utilisateur
- 1 x Câble AUX
- 1 x Télécommande
- 1 x Adaptateur USB à prise murale 10V1A

Comment charger le « Techno 0124 » (Batterie rechargeable intégrée)

1. Branchez le « Techno 0124 » à l'aide de l'adaptateur USB 10V et du câble murale inclus.
2. La lumière DEL rouge s'allumera pendant le chargement et s'éteindra lorsque le chargement sera complet.
3. Débranchez le câble USB une fois le chargement complet.

Note :

La batterie rechargeable intégrée est en mesure de recharger la batterie lorsque l'appareil est utilisé dans un endroit ensoleillé.

Télécommande

1. **Mise sous tension « on/off »**
2. **Volume+** : Maintenez enfoncé pour monter le volume, appuyez rapidement pour aller aux pistes suivantes
3. **Volume-** : Maintenez enfoncé pour monter le volume, appuyez rapidement pour aller aux pistes précédentes
4. **Play/Pause** **Bluetooth** disconnection :
Maintenez enfoncé pour déconnecter le **Bluetooth**.
Lorsqu'en mode **Bluetooth**, appuyez rapidement pour faire jouer la musique ou faire pause (seulement en mode **Bluetooth**)
5. **Allumer/Éteindre les lumières DEL**

Mettre le « Techno 0124 » en marche

Maintenez la touche On/Off de la télécommande enfoncée pendant 3 secondes.

Coupler le « Techno 0124 » à votre téléphone ou à votre tablette avec **Bluetooth.**

1. Allumez le « Techno 0124 » : les lumières DEL bleues et rouges clignoteront rapidement, indiquant que l'appareil est en attente de couplage.

2- Mettez le **Bluetooth de votre téléphone/tablette en fonction et cherchez les périphériques **Bluetooth**.**

Choisissez « Techno 0124 » dans la liste affichée par **Bluetooth**.

Une fois le couplage réussi, appuyez sur « connexion ».

La lumière DEL bleue restera allumée (sans clignoter), indiquant que le couplage a fonctionné.

Note :

1. Si le couplage n'a pas fonctionné, éteignez le haut-parleur, rallumez-le, puis essayez à nouveau la procédure de couplage.
2. Une fois le premier couplage effectué, les appareils couplés resteront en mémoire, évitant ainsi de devoir répéter la procédure lors des prochaines utilisations. (Note : Vous devrez procéder à nouveau au couplage si le haut-parleur a été effacé de la liste **Bluetooth**).
3. Pour coupler le haut-parleur avec un autre appareil, déconnectez le « Techno 0124 » de l'appareil en cours d'utilisation en appuyant sur la touche . Pour coupler avec un autre appareil, refaites les étapes 1-4.

Coupler le « Techno 0124 » à un iPhone/iPad ®

1. Gardez le (iPhone/iPad) ® à une distance de 1 mètre (3 ft) du « Techno 0124 » pendant le couplage.
2. Allumez le « Techno 0124 » : les lumières DEL bleues et rouges clignoteront rapidement, indiquant que l'appareil est en attente de couplage.
3. Sur votre (iPhone/iPad) ®, suivez le chemin suivant : Général > **Bluetooth**, appuyez sur la fonction **Bluetooth**, puis cherchez les périphériques **Bluetooth**, et choisissez le « Techno 0124 » pour vous connecter.

Pour se reconnecter à un appareil couplé (iPhone/iPad) ®

1. Votre (iPhone/iPad) ® se connectera automatiquement au dernier appareil couplé (le périphérique doit être en marche).
2. Si la connexion ne se fait pas automatiquement, sélectionnez le « Techno 0124 » dans la liste apparaissant à l'écran de votre (iPhone/iPad) ®.

Concernant le volume

1. Contrôlez le volume sur l'appareil couplé avec **Bluetooth** directement.
2. Contrôlez le volume avec les touches volume +/- de la télécommande.

Comment utiliser le port auxiliaire (pour les appareils n'ayant pas le **Bluetooth)**

1. À l'aide du câble AUX inclus, branchez le « Techno 0124 » au port auxiliaire de n'importe quel appareil de musique.
2. Faites jouer la musique grâce aux appareils ainsi connectés.

Note : Seules les touches « Volume+/- » & « Éclairage DEL » fonctionnent en mode auxiliaire.

Pour allumer les lumières

Appuyez sur la touche de la télécommande pour allumer/éteindre les lumières.

Industry Canada Notice

This device complies with Industry Canada licence-exempt RSS standard(s).

1. Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Avis d'Industrie Canada

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. Cet appareil numérique ne dépasse pas les niveaux d'interférence radio par un appareil numérique de classe B stipulés dans le Règlement sur l'interférence radio d'Industrie Canada.

Si vous devez vous débarrasser de cet appareil, ne le jetez pas aux ordures; il existe des centres de récupération des appareils électroniques. Consultez les autorités locales compétentes ou votre fournisseur pour plus de détails (directive relative aux Déchets des équipements électriques et électroniques).

LES CARACTÉRISTIQUES ET L'ASPECT EXTERNE DE L'APPAREIL SONT SUJETS À CHANGEMENTS SANS PRÉAVIS.