

<div data-bbox="156 638 427 712" data-label="Image"> </div> <div data-bbox="100 757 462 969" data-label="Image"> </div>	<div data-bbox="756 591 790 607" data-label="Text"> <p>28cm</p> </div> <div data-bbox="592 645 1005 694" data-label="Text"> <p><u>Read all safety and operation instructions before using the Turbo Speaker</u></p> </div> <div data-bbox="571 723 866 748" data-label="Section-Header"> <p>Important Safety Instructions:</p> </div> <div data-bbox="566 775 1042 1088" data-label="List-Group"> <ol style="list-style-type: none"> 1. Do not expose the speaker to liquid, moisture or areas of high humidity. 2. Do not use abrasive cleaners to clean the speaker's case as they may damage the unit. Always unplug and power off the unit before cleaning. 3. Do not expose the speaker to extremely high or low temperatures. 4. Keep the unit away from direct sunlight. 5. Do not attempt to open or modify the speaker in any way. 6. Store the speaker in a cool dry place. 7. The speaker should be situated so that its location </div>	<div data-bbox="1086 645 1544 721" data-label="Text"> <p>or position does not interfere with its proper ventilation. It should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings.</p> </div> <div data-bbox="1066 732 1540 871" data-label="List-Group"> <ol style="list-style-type: none"> 8. The Turbo Speaker contains a lithium ion battery. Lithium ion batteries are flammable and can cause fire if misused or defective. 9. Always dispose of the packaging and unit in accordance with the local regulations and in a responsible manner </div> <div data-bbox="1066 898 1335 922" data-label="Section-Header"> <p>Turn Turbo Speaker On/Off:</p> </div> <div data-bbox="1066 931 1551 981" data-label="Text"> <p>Toggle the power button to turn the Turbo Speaker on or off. The indicator light will light blue when the speaker is on.</p> </div> <div data-bbox="1066 1008 1425 1030" data-label="Section-Header"> <p>Using Bluetooth: Pairing Your Device:</p> </div> <div data-bbox="1066 1039 1513 1088" data-label="List-Group"> <ol style="list-style-type: none"> 1. The speaker needs to be paired to a Bluetooth device before using. </div>
<div data-bbox="78 1133 536 1395" data-label="List-Group"> <ol style="list-style-type: none"> 2. Power on the speaker then press and hold the power button on the speaker for a few seconds until the speaker plays an audible tone. The indicator light will flash in blue letting you know that the speaker is ready to be paired. 3. Activate the Bluetooth function on your device and search for and pair to the "Turbo Speaker" from the list. The speaker will automatically connect with your device and the indicator light will show a steady blue light once the pairing is complete. </div> <div data-bbox="79 1413 217 1433" data-label="Section-Header"> <p>Auxiliary Input:</p> </div> <div data-bbox="79 1438 521 1482" data-label="Text"> <p>Use a 3.5mm audio cable to connect the speaker to another audio source.</p> </div> <div data-bbox="79 1494 303 1514" data-label="Section-Header"> <p>Charging the Turbo Speaker:</p> </div> <div data-bbox="79 1518 526 1563" data-label="List-Group"> <ol style="list-style-type: none"> 1. Connect the micro USB plug to the micro USB charging port on the bottom of the Turbo Speaker. </div>	<div data-bbox="563 1137 1018 1330" data-label="List-Group"> <ol style="list-style-type: none"> 2. Connect the standard USB plug end of the cable to a power USB port on a computer or other USB charging device. 3. An indicator light of red means the unit is charging. Once fully charged, the indicator light will turn off. The charging process can take 2 to 3 hours to charge the battery. </div>	

FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.