







ON/OFF FEED CUT

**MAX**


CPM-200

**Берор**














**CAUTION**  
• THE MACHINE MAY CAUSE AN ACCIDENTAL INJURY.  
DO NOT INSERT FINGERS HERE.

**REQUEST**  
DO NOT CARRY THE UNIT BY HOLDING THE LID.



**CAUTION**  
↓ DO NOT INSERT FINGERS HERE. ↓





**CAUTION**  
DO NOT TOUCH AS THE  
PRINT HEAD CAN BE HOT.

**HOW TO LOAD A CARTRIDGE**  
1. INSERT END TABS ON CARTRIDGE  
INTO SLOTS.  
2. ROTATE THE CARTRIDGE UPWARD  
AND PUSH IT IN FIRMLY UNTIL IT  
CLICKS INTO PLACE.

