






## SAR Test Setup Photographs

EUT Side Definition		
Mode	Side	
1	Side 1	
2	Side 2	
3	Side 3	
4	Side 4	
5	Side 5	
6	Side 6	
<p>Note: We choose the maximum results of each test positions to provide the cube locations.</p>		



Phantom Position : Flat	EUT side : Side1
Spacing to phantom : 10 mm	Accessory : N/A





Phantom Position : Flat	EUT side : Side2
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side3
Spacing to phantom : 10 mm	Accessory : N/A





Phantom Position : Flat	EUT side : Side4
Spacing to phantom : 10 mm	Accessory : N/A





Phantom Position : Flat	EUT side : Side5
Spacing to phantom : 10 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side6
Spacing to phantom : 10 mm	Accessory : N/A

