


zoomBox

ZB-DM-001


Quick start guide

"An integrated system for Zoom Video conferencing"

Package Contents




Step.1 Set up zoomBox



Step .2 Network Settings


Ethernet Plug the ethernet into the zoombox device



Wi-Fi


1.Select [Setting]

2.Select your wi-fi and key-in password




Step.3 Jabra SPEAK™ 510 setting


1.Turn on Jabra 510




2.Press and hold (2 secs) the Bluetooth button on the Jabra SPEAK™ 510 until the Bluetooth light flashes blue




3.Select [Setting]



4.Turn on bluetooth




5.select Jabra 510




Step.4 Start to join your first meeting


1.Select [Start ZOOM]




2.Sign in your ZOOM account




3.Start a Meeting




1.Select [Join meeting]




2.Enter the Meeting ID of the meeting you want to join




3.Start a video conferencing



Back View



Front View



Power LED	Blue: On mode : Red: standby mode
USB	Only support USB Mouse and Keyboard into USB port
Ethernet	Connects to the RJ-45 Ethernet 10/100 based network. Not compatible with the telephone line.
HDMI	Connects to the HDMI jack on the display; a single cable transmits both audio and video data.
DC Jack	Connects to the DC output of the power adapter(5V/2A).

Operating Temperature / Operating Humidity	0 ~ 40°C / 80% RH (non-condensing)
Storage Temperature / Storage Humidity	-5 ~ 45°C / 80% RH (non-condensing)

Frequently Asked Questions

How Much Bandwidth Do I Need ?

For 1:1 video calling: 600kbps (up/down) for HQ video and 1.5 Mbps (up/down)
For group video calling: 600kbps/1.5Mbps (up/down) for HQ video.
For gallery view: 1.5Mbps/1.5Mbps (up/down).

How Do I Share My Screen?

- Plug the USB drive into the zoombox device
- Start or join a meeting .
- Open the Zoom menu and press the Share button
 - Photo** - share from your device and USB drive Gallery
 - Document** - share a PDF, photo from your USB drive
 - Dropbox** - share a photo or PDF from your Dropbox folders
 - OneDrive** - share a photo or PDF from your OneDrive folders
 - Web (Or From Bookmark)** - share a website from Zoom's built-in browser

Network firewall settings or web security gateway settings.

We recommend whitelisting ***zoom.us** ***zoomnow.net** from web security gateway's SSL inspection.

To configure your network firewall, please see:

Protocol	Ports	Source	Destination
TCP	443, 8801, 8802	All Zoom Clients	*.zoom.us *.zoomnow.net
UDP	8801, 8802	All Zoom Clients	*.zoom.us *.zoomnow.net

<div>Class B: (Section 15.105)</div> <div>FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT</div> <div>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div>	<div><div>- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/ TV technician for help.</div><div>Class B: (Section 15.105)</div><div>CAUTION:</div><div>Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.</div></div>
<div>RF exposure warning</div> <div>This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.</div>	<div>Warranty information</div> <div>Warranty Registration Please visit the website : http://zoombox.co/zoombox_warranty.php</div> <div>Warranty Policy Please visit the website : http://zoombox.co/zoombox_warranty_rule.php</div>
<div>More information</div> <div><div>zoombox website: http://zoombox.co</div><div>zoom website: https://zoomnow.net</div><div>FAQ: https://zoomnow.net/faq</div><div>Email: zoombox@zoomnow.net</div></div>	

User Scenario

