

## Install the Batteries


Wireless keyboard uses two AAA alkaline batteries,

Wireless mouse uses one AA alkaline battery

### Install Batteries in the Mouse

Step 1. Open the battery compartment


Step 2. Insert the batteries as shown into the battery compartment, and put back the cover



### Install the battery in the keyboard

Step 1. Remove the battery compartment cover on the bottom of the keyboard

Step 2. Insert the battery into the battery compartment, put back the cover.




## Connect the USB Receiver

1. Pick the USB receiver out from the rear side of the mouse.

2. Insert the USB receiver into USB port.

3. The connection will be done automatically.



## Multimedia Hotkeys functions:

FN+ESC=Media Player

FN+F1=Play/Pause

FN+F2=Previous Track

FN+F3=Next Track

FN+F4=Volume Up

FN+F5=Volume Down

FN+F6=Mute(Windows)

FN+F7=Web home

FN+F8=Search

FN+F9=Favorite

FN+F10=Email

FN+F11=Lock key

FN+F12=My computer


## State of standby and wake up the mouse

Your RF2.4GHz mouse have energy saving model, when no any click or scroll or move, the mouse will come to sleep status in about 8 minutes; to wake up, you can scroll the wheel or click any button for this. (On this energy saving, the optical LED will turn off, so, the mouse moving will not be responded)


## Store the receiver on the mouse

1:when you want use the mouse, you can take out the receiver to computer by the list ① step;

2:when you need stop the work or to travel, you can store the receiver on the mouse for the moving by the list ② step.



① Take out the receiver



② Store the receiver

## Power-Save function:

\* This mouse is equipped with Traveling-Power-Save function.

When you are traveling with this mouse, the LED of the mouse will be switched off automatically for the purpose of power-save, but the pre-condition is that the receiver is disconnected with your notebook or PC.

\* when no any click or scroll or moving, the mouse will come to sleep status for energy saving after about 8 minutes, to wake up, you can scroll the wheel or click any button for this

## Restore factory default settings

When you find this set doesn't work, you can make the mouse back to working condition by restoring the mouse back to factory default settings.

- 1: Check the battery volume is normal; if the battery is used out, please replace new batteries.
- 2: For mouse, reinsert the USB receiver onto the USB port of PC or notebook, then reinstall battery again to mouse.
- 3: For the keyboard, reinsert the USB receiver onto the USB port of PC or notebook, then reinstall battery again to mouse.

### FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.


Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Model:WKM-13, WKM-23

# Instruction Manual

## RF2.4GHz Auto-Link Keyboard & Optical Mouse



CAUTION: To use this device properly, please read the user's guide before installation.