


395X270mm

User Manual

Outdoor
Gourmet®

OG Bluetooth Thermometer

Style#155509



OG Bluetooth Thermometer

Thank you for selecting OG Bluetooth Thermometer. Simply program your choice of meat type ,target temperature or cooking time either on the touch key display unit you are your OG Bluetooth device via the corresponding app. When your grill is cooked to perfection, you do not need to wait by the grill to monitor the cooking status, Best of all the app allows you to even text-integrating photos of dishes on social community.

Connect with your mobile device

To quickly find the application from the Apple Store,please type "OG Bluetooth Thermometer"as keyword in the search engine.Ensure your mobile device is compatible with IOS 7 and later with Bluetooth v4.0.You can remotely set the OG Bluetooth Thermometer and read the thermometer information through Bluetooth v4.0 with your mobile device.

ios series model


Iphone (4s and later)
Ipad (3rd generation and later)
Ipad mini (all generations)
Ipod touch (5th generation and later)

Android series model

Android 4.3 above.

Pairing your Outdoor Gourmet

First of all,you need to pair your thermometer with your mobile device. It will display as Fig.1 . Install the battery into the thermometer, Press Search, APP will start to search the device. After successful pairing will display as Fig.2 .






Fig.1

Fig.2

1.Profile (Tap to toggle the temperature ad timer options)

2.Food display

3.Settings the temperature display


4.Tasking mission

5.Tasking indicator the mission

6.Metal probe temperature

7:Cooking timer

8.Start/stop mission

Press  go Home display

Display unit--work

Pls refer Fig.3.




Fig.3

Settings

Press settings to enter to select the measurement unit:

1) Back Home

2) °C/°F switch

3) Food ,temperature choose

4) Select the temperature

5) Timer setting

6) Alarm setting

Settings the choose food

You can set your thermometer through the application, such as measurement units,The settings are as follows.

To select food:


1. Tap to view the Profile options food.


2. Tap on your food type.


3. Tap to select cooking degree and temperature can be adjusted up and down degrees.

4. Tap add your new food.

Pls refer Fig.4-7.










Fig.4


Fig.5


Fig.6

Fig.7

Settings the definition temperature

You can freely set alarm temperature by remote device








Fig.8

Fig.9

Fig.10

To select the temperature

1. Tap to view the Profile options of temperature.

2. Slide down and up to set temperature you need.

3. Tap to go back to the previous screen to save.

Pls refer Fig.8-9.

Timer setting

You can freely set alarm time of your thermometer by remote device

1. Tap to view the Profile options of timer

2. Slide down and up to set temperature you need.Timer measurement range: 23H59M59S

3. Tap to go back to the previous screen to save

Pls refer Fig.10.

Alarm setting

To select the alarming:You can choose any alarm ring from 15 rings.


1. Tap to view the Profile options of rings.

2. Tap to choose your favorite ring.

3. Tap to go back to the previous screen to save.

4. If food is cooked, alarm ring will ring and show notification menu.

Temperature will show on the screen and display will flash.
Pls refer Fig.11-12.







Fig.11

Fig.12

View history

Tap on temperature in central.You can view history date which is presented in graphs.

Pls refer Fig.13-14.






Fig.13

Fig.14

Sharing

You can put the food cooking photos in community and share with others.


To select the camera


1. Tap to choose your favorite camera.

2. Tap on camera button.

3. Tap on share button and food cooking photos you took will be shared in your community.

Pls refer Fig.15-17.








Fig.15

Fig.16

Fig.17

NOTE

If the voltage of battery is low, the product will work badly.
Please turn off the device if the APP cannot search the device, then turn it on and try to search it again.

FCC CAUTION:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including in interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or televisi on reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. ⚡

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.⚡

1 YEAR LIMITED WARRANTY.

This product has been manufactured under the highest standards of quality and workmanship. We warrant to the original consumer purchaser that all aspects of this product will be free of defects in material and workmanship for one year from the date of purchase. A replacement for any defective part will be supplied free of charge for installation by the consumer. Defects or damage caused by the use of other than genuine parts are not covered by this warranty. This warranty shall be effective from the date of purchase as shown in the purchaser receipt. This warranty is valid for the original consumer purchaser only and excludes industrial, commercial or business use of the product, product damage due to shipment or failure which results from alteration, product abuse, or product misuse, whether performed by a contractor , service company , or consumer. We will not be responsible for labor charges and/or damage incurred in installation, repair or replacement nor for incidental or consequential damage.

Customer Service: (888) 922-2336
7:00 am to 12:00 am CST (daily)
Live Chat at: www.academy.com

(Made in China)