


SwitchBot Hub Quick Start



SwitchBot Hub



Magnet



Adapter





Guide

SwitchBot Hub S1




1. Power on your SwitchBot Hub and launch the SwitchBot App downloaded from your app store.

2. Start to add your Hub from the left side menu. Then set the backside switch of the device from "AUTO" to "ON" .




3. Follow the app instructions to add the device and set your local SSID and password of your WiFi router. The Hub will start rainbow showing after successfully connected to a WiFi router.

4. Back to the main page in the App and now you are ready to control SwitchBots via this Hub.



ON (top): Light is always on; Pairing mode within 10 minutes.
OFF (middle): Light is always off.
Auto (bottom): Light will be activated when the Hub status changes.

(Optional) Peel off the tape and stick the magnet to a wall. Then attach your Hub to the magnet and enjoy.



This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID: 2AKXB-HUBS1