

Fabric Speaker with Wireless Charging

Instruction Manual

Speaker part:.

Specifications

1. Working voltage:3.4-4.2V
2. Charging power supply: DC5V/880mA (Battery Indicator LED is red when charging. Turns off when fully charged).
3. Low power warning: When voltage is lower than 3.4V, two beeps will sound and the battery indicator LED will flash blue.


Operation

Turn on speaker using the switch button located on the middle .

The LED indicator will flash in blue.

the device is in pairing mode.

A. Bluetooth mode – pairing with”Forward Speaker”

1. The blue flashing LED indicates pairing mode. Once a connection with media device has been established, the flash will slow, remaining blue.
2. “-” Button: Click to skip to decrease volume. Press and hold to previous track
3. “” Button: Click to pause/play music, answer incoming calls.
4. “+” Button: Click to skip to increase volume. Press and hold to next track.

Charging the speaker:

Using a regulated USB adapter .Connect a USB cable to a USB adapter.

Usingthe

Micro-USB connector, connect the other end of the USB cable to the charging port onthe speaker. Plug the USB adapter into theoutlet to begin charging.

The LED will light up inred while in charging, turns off when fully charged.

Wireless Charger part.

Specifications:

Input: 5V/Max.2000mA

Output: 5V/750mA

Charging Efficiency: $\geq 70\%$

Interface: Micro USB port

Easy To Use

1. Connect the Micro-USB tip to the input port
 - a.Connect the provided Micro-USB cable to the USB plug adapter.
 - b.Connect the Micro-USB tip to the input port on the product.
- 2.Charging Mobile Devices:

a. Place the enabled device on the surface of the top wireless charging pad. The device should display charging indicator.

b. When completely charged, remove the device from the charging pad.

LED Indications:

While device is charging LED will illuminate WHITE. Once the device is fully charged, the white LED

will turn off.

Compatible Models:

- Galaxy S6 / S6 edge / S6 edge+ / Note 5/ S7 / S7 Edge / S8 / S8 Plus
- Nokia Lumia 950 XL / 950 / 920 / 928 / 930
- Google Nexus 6, Google Nexus 5, Google Nexus 4
- HTC 8X (Verzion Wireless), HTC Droid DNA, HTC Rround, HTC Droid Incredible 4G LTE;
- LG D1L, LG Optimus LTE2;
- Sharp AQUOS Slider SH-02D, Q-Pot SH-04D; AQUOS SH-07D, AQUOS SH-13C;
- iPhone 8, iPhone X
- other Qi devices

FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

For Wireless Charger part

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

For Bluetooth

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.