

#### OPERATING INSTRUCTIONS

1. PRESS START TO STEP THROUGH 5 SPEEDS.
2. PRESS STOP TO HALT FAN AT ANY TIME.
3. PRESS SET RUN HOURS TO SELECT RUN TIME.  
SELECTION ON RUNS UNTIL STOP IS SELECTED.

#### INSTRUCCIONES PARA OPERAR

1. PRESIONE EL BOTÓN START PARA COMENZAR DE LA LERA A LA 5ª VELOCIDAD.
2. PRESIONE EL BOTÓN STOP PARA PARAR EL ABANICO EN CUALQUIER MOMENTO.
3. PRESIONE EL BOTÓN SET RUN HOURS PARA SELECCIONAR EL TIPO DE CUAL CUALQUIER TIPO DE ABANICO. ESTA SELECCION ON CORRER EL ABANICO HASTA QUE LISTO LO APLICAR STOP.

MODEL NO. WHSP 2000

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

Operation is subject to the following two conditions:

- 1) This device may cause harmful interference.
- 2) This device must accept any interference received,  
including interference that may cause undesired operation.

 **AIR VENT INC.**  
A GIBRALTAR COMPANY

Whisper Mode




Exhaust Mode

START

STOP

SET SPEED

ON  
4  
2  
1  
1/2



SET RUN HOURS

### Easy Operation

- Use exhaust mode for quick cool
- Then use lower settings for continuous circulation

*Whisper*Aire™

W H O L E - H O U S E F A N

18279