


NOTES:

1. Layout as GROUND star.
 - Mount RF914 flat to L206 PCB with plastic insulation.
 - Stand the antenna vertical Max height:24mm from top side of PCB.
 - Solder antenna on top and bottom of PCB.



R1-18, 31, 32, C1-10, 18, U1-4, 6, B1, S1, D1, H1