











RJ45 connector - here you can connect either USB or RS232 interconnection cable