

Photo number 1.
Overall EUT using USB interface.



Photo number 2.
EUT using either USB or Ethernet interface.
Front side.





Photo number 3.
EUT using either USB or Ethernet interface.
Back side.



Photo number 4.
EUT using either USB or Ethernet interface.
Right side.

Photo number 5.
EUT using either USB or Ethernet interface.
Left side.



Photo number 6.
EUT using either USB or Ethernet interface.
Bottom side.



Photo number 7.
EUT using USB interface.
Top side.



Photo number 8.
EUT using either USB or Ethernet
interface.
Back side labels.




Photo number 9.
EUT using either USB or Ethernet interface.
Back side agencies.



Photo number 10.
EUT using USB interface.
Back cover removed.

