

## **ATTACHMENT J.**

**- DC Voltages and Currents of RF components -**

## GRS-2630D-SPR(Voltage and Current of Modules)

Item	Voltage	Current
LNA	7V	600mA
Converter	7V	2.0A
LED Board	5V	100mA
RFC Board	5V	150mA
NMS Board	50V	250mA
AMP	29V	4.0A