


6. SETUP PHOTOS

DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP


MASTER:




DFS BACK PHOTO



SLAVE:



DFS BACK PHOTO



END OF REPORT