











Resistor	R38	R40	R83	R109	R110	R111	R112	R113
QV1501			X	X	X	X	X	X
QV1401	X	X						

X=Install jumper resistor









Title		
Atbox InternetVue IV2120: Power, Clock		
Size	Document Number	Rev
	TD-WAVF-012	1.31
Date:	Wednesday, January 23, 2008	Sheet 4 of 9




Title			
AtBox InternetVue IV2120: Memory			
Size	Document Number		Rev
	TD-WAVF-012		1.31
Date:	Wednesday, January 23, 2008	Sheet	5 of 9



J8	UART
1	2 RX
2	3 Tx
3	5 GND



AtBox Tech. EchoView Wireless Display Adapter



Title		
AtBox InternetVue IV2120: Fuctional Block Diagram		
Size	Document Number	Rev
	TD-WAVF-012	1.31
Date:	Wednesday, January 23, 2008	Sheet 9 of 9