



Synoptic of the PAM Reader



PAM Reader connections



- 1 : CSC card
- 2 : SAM card
- 3 : Lithium battery (3,5 Vdc)
- 4 : SubD 9 pins female connector
- 5 : RS-232 connector (DF13 - 8S-1.25 C)
- 6 : Power supply connector (DF13-2S-1.25 C)
- 7 : Battery connector (DF13 -3S-1.25 C)