



The 'warning' sticker on the WebRTU<sup>®</sup> Z2 is located on the bottom right side of the device.