



## **1. External Photograph of EUT**

**Brand Name:** TOSHIBA, Excite


**Model Name:** TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335





**Brand Name: TOSHIBA, Excite**

**Model Name: TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335**





## 2. Photograph of Accessory

Brand Name: TOSHIBA, Excite

Model Name: TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335

### List of Accessory:

Specification of Accessory		
AC Adapter 1	Brand Name	TOSHIBA (Lieton)
	Model Name	PA-1300-04
AC Adapter 2	Brand Name	TOSHIBA (Lieton)
	Model Name	PA-1300-03
AC Adapter 3	Brand Name	TOSHIBA (Delta)
	Model Name	PA3922E-1AC3
AC Adapter 4	Brand Name	TOSHIBA (Delta)
	Model Name	PA3922U-1ACA
Battery	Brand Name	Simplo (Toshiba)
	Model Name	PA5055U-1BRS
I/O Cable	Brand Name	FOXCONN
	Model Name	CQV40D05UB04-X02-EF

**Remark:** For accessories equipped with this EUT, please refer to the following photos.

**Brand Name:** TOSHIBA, Excite

**Model Name:** TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335



Brand Name: TOSHIBA, Excite

Model Name: TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335

AC Adapter 1





Brand Name: TOSHIBA, Excite

Model Name: TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335

AC Adapter 2



Brand Name: TOSHIBA, Excite

Model Name: TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335

AC Adapter 3





Brand Name: TOSHIBA, Excite

Model Name: TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335

## AC Adapter 4





Brand Name: TOSHIBA, Excite

Model Name: TOSHIBA AT330, Excite 13 AT330, Excite 13 AT335

