




Boot configuration	X TEST MODE[5:0]
Boundary Scan	6b110000
SLC Nand Boot 2KB Page 8 Bit	6b000101
MLC Nand Boot 2KB Page 8 Bit	6b001000
INAND Boot	6b001100
EFuse	6b110010
MLC Nand Boot 4KB Page 8 Bit	6b001001

YF-INTERNATIONAL		
Title YF Atlas-IV		
Size A	Document Number MLC NAND/Debug	Rev V01
Date: Friday, April 24, 2009	Sheet 5	of 16



YF- INTERNATIONAL		
Title YF Atlas-IV		
Size A	Document Number Audio	Rev V01
Date: Friday, April 24, 2009	Sheet 6	of 16








GPS RF Receiver core

Must be placed into RF shielding case

YF- INTERNATIONAL		
Title		
YF Atlas-IV		
Size	Document Number	Rev
Custom	GPS RF	V01
Date:	Friday, April 24, 2009	Sheet 8 of 16



YF-INTERNATIONAL		
Title		
YF Atlas-IV		
Size	Document Number	Rev
A	TF/SD Card	V01
Date:	Friday, April 24, 2009	Sheet 9 of 16

