



NOTE: 1. The buttons Named in PS3/XBOX360/Wii(classic) format;  
 2. "()" in button name signed PS2/XBOX/GC;  
 3. "[ ]" in button name signed nunchuck for Wii;  
 4. Left stick also used in nunchuck;  
 5. Only PS3/XBOX/HOME button can wakeup, so layout for nunchuck, the

Update History			
Version	Author	Change	Reason
R15	2.4V	240Kohm	TBD
	4.5V	470Kohm	
	6.0V	560Kohm	
R16	2.4V	220Kohm	TBD
	4.5V	220Kohm	
	6.0V	220Kohm	

Title		
Size	Number	Revision
A3		Ver0.6
Date:	27-May-2008	Sheet of 1 / 1
File:	E:\Work\备份夹\Nunchuck & Classic SQ2020\0611.DDB	Alex