

Test setup photos of KT400

1. Conducted Emission Test setup

Data transmitting via USB port




Diagnostic mode




2. Radiated Emission Test


Data transmitting via USB port (below 1GHz)



Data transmitting via USB port (Above 1GHz)



Diagnostic mode(below 1GHz)



Diagnostic mode(Above 1GHz)

