


APPENDIX IV

Internal Photos


EUT – Uncovered View (HLT3PAR16W)



EUT –Components View (HLT3PAR16W)




EUT–Solder View (HLT3PAR16W)




EUT – Uncovered View (HLT3PAR23W)



EUT –Components View (HLT3PAR23W)




EUT–Solder View (HLT3PAR23W)




EUT – Uncovered View (HLT3R23W)



EUT –Components View (HLT3R23W)




EUT – Solder View (HLT3R23W)




EUT – Uncovered View (HLT3R16W)



EUT –Components View (HLT3R16W)



EUT–Solder View (HLT3R16W)




EUT – Uncovered View (HLT3R14W)



EUT –Components View (HLT3R14W)



EUT–Solder View (HLT3R14W)




EUT – Uncovered View (HLT3G14W)



EUT –Components View (HLT3G14W)




EUT–Solder View (HLT3G14W)




EUT – Uncovered View (HLT3G09W)



EUT –Components View (HLT3G09W)




EUT–Solder View (HLT3G09W)




EUT – Uncovered View (HLT3A14W)



EUT –Components View (HLT3A14W)




EUT–Solder View (HLT3A14W)




EUT – Uncovered View (HLT3A09W)



EUT –Components View (HLT3A09W)



EUT–Solder View (HLT3A09W)




EUT – Uncovered View (HLT3GU23W)




EUT –Components View (HLT3GU23W)



EUT–Solder View (HLT3GU23W)



EUT – Uncovered View (HLT3GU26W)



EUT –Components View (HLT3GU26W)



EUT-Solder View (HLT3GU26W)

