















DUAL 32M Byte SDRAM chip SDRAM_3.3V











Jz4740_V1.4




USB_DEVICE





USB_HOST








Title		
PWS700B		
Size B	Document Number	Rev 1.2
LCD & SD Card		
Date:	Tuesday, December 02, 2008	Sheet 3 of 7



Title		
PWS700B		
Size B	Document Number	Rev 1.2
AUDIO		
Date:	Tuesday, December 02, 2008	Sheet 4 of 7



Date: Tuesday, December 02, 2008 Sheet 5 of 7



Title		
PWS700B		
Size	Document Number	Rev
B	Keyboard_TouchPad_WiFi	1.2
Date:	Tuesday, December 02, 2008	Sheet 6 of 7

