

SAR Test Setup Photographs

EUT Setup up Photo



Body Setup




Figure 1. Body SAR Test Setup (Flat Section)_ Horizontal Down _ straight mode_ 5mm_ with USB Cable




Figure 2. Body SAR Test Setup (Flat Section) _Horizontal Up_5mm_antenna open 90 degrees mode_ LCD open 90 degrees




Figure 3. Body SAR Test Setup (Flat Section)_Horizontal Up_straight mode_5mm_LCD open 90 degrees



Figure 4. Body SAR Test Setup (Flat Section)_Horizontal Up_straight mode_10mm_ LCD open 90 degrees