

■ TEST CONFIGURATION POSITIONS

The exterior of the device



Position: Front of EUT



Position: Rear of EUT



Position: Top of EUT



Position: Bottom of EUT



Position: Right of EUT



Position: Left of EUT


■ Test Setup Photo(Body SAR Test Photo)




■ Test Setup Photo(Position A: Top)




■ Test Setup Photo(Position B: Bottom)



■ Test Setup Photo(Position C: Front)




■ Test Setup Photo(Position D: Rear)



■ Test Setup Photo(Position E: Right)



■ Test Setup Photo(Position F: Left)



■ Test Setup Photo(Edge Curve #1)



■ Test Setup Photo(Edge Curve #2)

