

Figure 1
Inside of the EUT
Speaker




Figure 2
Inside of the EUT
Speaker




Figure 3
Inside of the EUT
Speaker




Figure 4
Inside of the EUT
Speaker




Figure 5
Inside of the EUT
Speaker





Figure 6
Inside of the EUT
USB Transmitter



Antenna

Figure 7
Inside of the EUT
USB Transmitter




Figure 8
Inside of the EUT
Docking



Figure 9
Inside of the EUT
Docking




Figure 10
Inside of the EUT
Docking




Figure 11
Inside of the EUT
Docking




Figure 12
Inside of the EUT
Docking




Figure 13
Inside of the EUT
Docking




Figure 14
Inside of the EUT
Docking

