

## STARTER DRAIN ON THE ACCESSORY DRIVE GEARBOX - ADJUSTMENT/TEST

*EFFECTIVITY: POST-MOD. S.B. AE3007A-72-253 AND PRE-MOD. S.B. AE3007A-72-330*

### 1. General

- A. This section gives the procedures to do the check of the starter drain adapter of the accessory drive gearbox.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
72-63-02-700-801-A ♦	STARTER DRAIN ADAPTER CHECK	POST-MOD. S.B. AE3007A-72-253 AND PRE-MOD. S.B. AE3007A-72-330

TASK 72-63-02-700-801-A

EFFECTIVITY: POST-MOD. S.B. AE3007A-72-253 AND PRE-MOD. S.B. AE3007A-72-330

## 2. STARTER DRAIN ADAPTER CHECK

### A. General

(1) Obey these instructions to do the operational check of the starter drain adapter.

### B. References

REFERENCE	DESIGNATION
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING
Rolls-Royce MM CSP 34022	-

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
415		LH Engine
425		RH Engine

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the engine	1

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

### I. Preparation

SUBTASK 841-002-A

**WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN AMM MPP 71-00-00/200 TO PREVENT INJURY TO PERSONS AND DAMAGE TO MATERIAL.**

- (1) On the circuit breaker panel, open the circuit breaker below and attach a DO-NOT-CLOSE tag to it:
  - START 1/2.
- (2) Put the workstand in the work area.
- (3) Open the lower cowling ( [AMM TASK 71-12-01-000-801-A/400](#)).

J. Starter Drain Adapter - Operational Check

*SUBTASK 710-002-A*

- (1) Do an operational check of the starter drain adapter of the accessory drive gearbox. Refer to the latest revision of Rolls-Royce MM CSP 34022.

K. Follow-on

*SUBTASK 842-002-A*

- (1) Close the lower cowling ( [AMM TASK 71-12-01-400-801-A/400](#)).
- (2) Remove the workstand.
- (3) On the circuit breaker panel, close the circuit breaker below and remove the DO-NOT-CLOSE tag from it.
  - START 1/2.

