

PORTABLE FIRE EXTINGUISHERS - REMOVAL/INSTALLATION

EFFECTIVITY: ALL

1. General

- A. This section gives the procedures for the removal/installation of the portable fire extinguishers.
- B. The location of the portable fire extinguishers of the passenger cabin is shown by means of glyphs. In the cockpit, it is installed behind the pilot seat.
- C. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
26-24-01-000-802-A	PORTABLE FIRE EXTINGUISHERS - REMOVAL	ALL
26-24-01-400-802-A	PORTABLE FIRE EXTINGUISHERS - INSTALLATION	ALL

TASK 26-24-01-000-802-A

EFFECTIVITY: ALL

2. PORTABLE FIRE EXTINGUISHERS - REMOVAL

A. General

(1) This task gives the procedure for the removal of the portable fire extinguishers.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin/cockpit

H. Removal [\(Figure 401\)](#)


SUBTASK 020-002-A

- (1) Get access to the fire extinguisher.
- (2) Open the Velcro fastener or belts, as applicable.
- (3) Remove the fire extinguisher from the support.

EFFECTIVITY: ALL

Portable Fire Extinguisher - Removal/Installation

Figure 401



1 ONLY CONSIDER THE TYPE AND LOCATION OF THE FIRE EXTINGUISHERS APPLICABLE TO YOUR AIRCRAFT CONFIGURATION.

2 FIRE EXTINGUISHER GLYPH

145AMM260191.MCE A

TASK 26-24-01-400-802-A

EFFECTIVITY: ALL

3. PORTABLE FIRE EXTINGUISHERS - INSTALLATION

A. General

(1) This task gives the procedure for the installation of the portable fire extinguisher.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin/cockpit

H. Installation (Figure 401)

SUBTASK 420-002-A

(1) Install the fire extinguisher at the support.

(2) Close the Velcro fastener or belts, as applicable.