

FLOOR PROXIMITY STRIP LIGHTS - MAINTENANCE PRACTICES

EFFECTIVITY: FOR AIRCRAFT WITH PHOTOLUMINESCENT STRIP LIGHTS

1. General

- A. This section gives the procedures to discard the Photoluminescent Floor-Proximity Strip Lights.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
33-50-12-900-801-A	PHOTOLUMINESCENT FLOOR-PROXIMITY STRIP LIGHTS - DISPOSAL	FOR AIRCRAFT WITH PHOTOLUMINESCENT STRIP LIGHTS

TASK 33-50-12-900-801-A

EFFECTIVITY: FOR AIRCRAFT WITH PHOTOLUMINESCENT STRIP LIGHTS

2. PHOTOLUMINESCENT FLOOR-PROXIMITY STRIP LIGHTS - DISPOSAL

A. General

(1) This task gives the procedures to discard the Photoluminescent Floor-Proximity Strip Lights.

B. References

REFERENCE	DESIGNATION
AMM TASK 33-50-12-000-802-A/400	-
AMM TASK 33-50-12-400-802-A/400	-

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
231		Passenger cabin
232		Passenger cabin
241		Passenger cabin
242		Passenger cabin
251		Passenger cabin
252		Passenger cabin
261		Passenger cabin
262		Passenger cabin

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

I. Photoluminescent Floor-Proximity Strip Lights - Disposal ([Figure 201](#))

SUBTASK 910-006-A

(1) Discard the Photoluminescent Floor-Proximity Strip Light as follows:

- (a) Remove and discard all the Photoluminescent Floor-Proximity Strip Lights. Refer to AMM TASK 33-50-12-000-802-A/400.
- (b) Install the new Photoluminescent Floor-Proximity Strip Lights. Refer to AMM TASK 33-50-12-400-802-A/400.

EFFECTIVITY: FOR AIRCRAFT WITH PHOTOLUMINESCENT STRIP LIGHTS

Photoluminescent Floor-Proximity Strip Lights

Figure 201

