

THERMOCOUPLES - ADJUSTMENT/TEST

EFFECTIVITY: ALL

1. General

- A. This section gives the procedure to do the electrical test of the thermocouple.
- B. These procedures are applicable to the LH and RH engines.
- C. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
77-21-01-700-801-A	THERMOCOUPLE - ELECTRICAL TEST	ALL

TASK 77-21-01-700-801-A

EFFECTIVITY: ALL

2. THERMOCOUPLE - ELECTRICAL TEST

A. General

(1) To do the test of the thermocouple, obey the instructions in Rolls-Royce MM CSP 34022.

B. References

REFERENCE	DESIGNATION
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-11-01-000-801-A/400	ENGINE UPPER COWLING - REMOVAL
AMM TASK 71-11-01-400-801-A/400	ENGINE UPPER COWLING - INSTALLATION
AMM TASK 71-12-01-000-802-A/400	ENGINE LOWER COWLING - REMOVAL
AMM TASK 71-12-01-400-802-A/400	ENGINE LOWER COWLING - INSTALLATION

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower Cowling	LH Engine
423	Lower Cowling	RH Engine
412	Upper Cowling	LH Engine
422	Upper Cowling	RH Engine

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Work Stand	To get access to the engine	1

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

I. Preparation

SUBTASK 841-002-A

WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN [AMM MPP 71-00-00/200](#) TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them.
 - START 1/2.
- (2) Put the work stand in the work area.
- (3) Remove the lower cowling ([AMM TASK 71-12-01-000-802-A/400](#)).
- (4) Remove the upper cowling ([AMM TASK 71-11-01-000-801-A/400](#)).

J. Electrical Test

SUBTASK 760-002-A

- (1) Do the electrical test of the thermocouple. Refer to the last revision of Rolls-Royce MM CSP 34022.

K. Follow-on

SUBTASK 842-002-A

- (1) Install the upper cowling ([AMM TASK 71-11-01-400-801-A/400](#)).
- (2) Install the lower cowling ([AMM TASK 71-12-01-400-802-A/400](#)).
- (3) Remove the work stand.
- (4) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them.
 - START 1/2.

