

## OIL TANK - SERVICING

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedure to drain the oil from the Oil Tank.
- B. The procedures in this section are given in the sequence below. The tasks identified with (◆) are part of the Scheduled Maintenance Requirements Document (SMRD).

<i>TASK NUMBER</i>	<i>DESCRIPTION</i>	<i>EFFECTIVITY</i>
79-11-01-600-801-A	OIL TANK - SERVICING	ALL

TASK 79-11-01-600-801-A

EFFECTIVITY: ALL

## 2. OIL TANK - SERVICING

### A. General

(1) To do the task, see the instructions contained in Rolls-Royce MM CSP 34022.

### B. References

REFERENCE	DESIGNATION
AMM MPP 71-00-00/200	- MAINTENANCE PRACTICES
AMM TASK 71-12-01-000-801-A/400	ENGINE LOWER COWLING - OPENING
AMM TASK 71-12-01-400-801-A/400	ENGINE LOWER COWLING - CLOSING
Rolls-Royce MM CSP 34022	-

### C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
413	Lower cowling	LH Engine
423	Lower cowling	RH Engine

### D. Tools and Equipment

Not Applicable

### E. Auxiliary Items

ITEM	DESCRIPTION	PURPOSE	QTY
Commercially available	Workstand	To get access to the engine	1

### F. Consumable Materials

Not Applicable

### G. Expandable Parts

Not Applicable

### H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Engine

### I. Preparation

SUBTASK 841-002-A

**WARNING: BEFORE YOU DO THE TASK, OBEY THE SAFETY PRECAUTIONS GIVEN IN AMM MPP 71-00-00/200 TO PREVENT INJURY TO THE PERSONS AND DAMAGE TO THE MATERIAL.**

- (1) On the circuit breaker panel, open the circuit breakers below and attach a DO-NOT-CLOSE tag to them.
  - START 1/2.
- (2) Put the workstand in the work area.
- (3) Open the lower cowling ( [AMM TASK 71-12-01-000-801-A/400](#)) to get access to the engine oil tank.

J. Tank Oil Drain

*SUBTASK 680-002-A*

- (1) Drain the oil tank. Refer to the latest revision of Rolls-Royce MM CSP 34022.

K. Follow-on

*SUBTASK 842-002-A*

CAUTION: MAKE SURE THAT THE LATCHES OF THE ENGINE SERVICING DOOR ARE CORRECTLY CLOSED. IF THE DOOR LATCHES ARE NOT CORRECTLY CLOSED, THE ACCESS PANEL MAY OPEN DURING THE FLIGHT.

- (1) Close the lower cowling ( [AMM TASK 71-12-01-400-801-A/400](#)).
- (2) Remove the workstand.
- (3) On the circuit breaker panel, close the circuit breakers below and remove the DO-NOT-CLOSE tag from them.
  - START 1/2.
- (4) Refer to the Rolls-Royce MM CSP 34022 to do the related check after an engine LRU maintenance procedure, as applicable.

