
PASSENGER CABIN ESCAPE HATCHES - SERVICING

EFFECTIVITY: ALL

1. General

- A. The procedure for the lubrication of the Passenger-Cabin Escape Hatches is given in [AMM TASK 52-21-00-600-801-A/300](#).

