



B


A

B

A



SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	2 IN. X 4 IN. X 16 FT. SPRUCE PINE FIR LUMBER
1.	USE A CIRCULAR SAW TO CUT A WOOD BLOCK WITH HEIGHT AND LENGTH APPROXIMATELY EQUAL TO DIMENSIONS GIVEN.
2.	USE A DRILL WITH A 1/8 IN. DRILL BIT TO DRILL THE SMALL PILOT HOLES. THE LOATION OF THE HOLES SHOULD FALL WITHIN TOLERANCES.
3.	USE A DRILL WITH A 55/64 IN. DRILL BIT TO DRILL THE LARGER HOLE. THE LOCATION OF HOLE SHOULD CORRESPOND TO THE GIVEN DIMENSIONS WITHIN TOLERANCE.
4.	SAND THE SIDES OF THE BLOCK UNTIL ALL DIMENSIONS ARE WITHIN TOLERANCE.



ISOMETRIC VIEW
FOR REFERENCE ONLY
SCALE 1:2

DRAWN BY ANDREW WEIR	DATE 11/21/2019	STOCK VENDOR INFO: HOME DEPOT MODEL # 0133166	
APPROVALS:		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGLES ARE IN DEGREES 3rd Angle Projection	
AU EMAIL	SINGNATURE	CARELESS BRONCOS	
		MATERIAL: Pine	
		TITLE/DESC: RELEASE CONNECTING SUPPORT	
		FILE NAME: Release support	
		DWG. #: P-041	REV #: A
		SCALE: 1:1	SIZE B
		SHEET 1 OF 1	