

4

3


2

1



SAMPLE FABRICATION/ASSEMBLY PROCESS

STOCK DESC/DIMS SELECT PINE BOARD 1in. X 6in. X 6ft.

1. USE A CIRCULAR SAW TO CUT A BLOCK WITH LENGTH AND HEIGHT APPROXIMATELY EQUAL TO DIMENSIONS GIVEN. THE WIDTH SHOULD CORRESPOND TO PURCHASED MATERIAL.
2. USE A DRILL WITH A BIT SIZE OF .75 IN TO CUT OUT A HOLE IN APPROXIMATE LOCATION GIVEN. THE LOCATION OF THE HOLE SHOULD FIT WITHIN TOLERANCES.
3. USE SAND PAPER TO SAND THE EDGES OF THE BLOCK AND HOLE UNTIL IT FITS WITHIN GIVEN TOLERANCES.



ISOMETRIC VIEW

FOR REFERENCE ONLY
SCALE 1:2

DRAWN BY Andrew Weir	DATE 11/18/2019	STOCK VENDOR INFO: HOME DEPOT MODEL #928787	
APPROVALS:		CARELESS BRONCOS	
AU EMAIL	SIGNATURE	MATERIAL: Pine	
		TITLE/DESC: RELEASE LEVER	
		FILE NAME: Release Lever	
		DWG. #: P-039	REV #: A
		SCALE: 1:1	SIZE B
		SHEET 1 OF 1	

4

3

2

1