


4

3


2

1

SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	SELECT PINE BOARD 1in. X 6in. X 6ft.
1.	USE A CIRCULAR SAW TO CUT A BLOCK WITH LENGTH AND HEIGHT APPROXIMATELY EQUAL TO DIMENSIONS GIVEN. THE WIDTH SHOULD CORRESPOND TO PURCHASED MATERIAL.
2.	USE A DRILL WITH A BIT SIZE OF .75 IN TO CUT OUT A HOLE IN APPROXIMATE LOCATION GIVEN. THE LOCATION OF THE HOLE SHOULD FIT WITHIN TOLERANCES.
3.	USE SAND PAPER TO SAND THE EDGES OF THE BLOCK AND HOLE UNTIL IT FITS WITHING GIVEN TOLERANCES.



ISOMETRIC VIEW
FOR REFERENCE ONLY
SCALE 1:2



DRAWN BY Andrew Weir	DATE 11/21/2019	STOCK VENDOR INFO: HOME DEPOT MODEL #928787	
APPROVALS:		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGLES ARE IN DEGREES 3rd Angle Projection	
AU EMAIL	SINGNATURE	CARELESS BRONCOS	
		MATERIAL: Pine	
		TITLE/DESC: RELEASE LEVER	
		FILE NAME: Release Lever	
		DWG. #: P-039	REV #: A
		SCALE: 1:1	SHEET 1 OF 1
		SIZE B	

3

2

1