



4

3


2

1



SAMPLE FABRICATION/ASSEMBLY PROCESS

- | STOCK DESC/DIMS | 2 IN. X 4 IN. X 16 FT. SPRUCE PINE FIR LUMBER |
|-----------------|---|
| 1. | USE A CIRCULAR SAW TO CUT A WOOD BLOCK WITH HEIGHT AND LENGTH APPROXIMATELY EQUAL TO DIMENSIONS GIVEN. |
| 2. | USE A DRILL WITH A 1/8 IN. DRILL BIT TO DRILL THE SMALL PILOT HOLES. THE LOCATION OF THE HOLES SHOULD FALL WITHIN TOLERANCES. |
| 3. | USE A DRILL WITH A 55/64 IN. DRILL BIT TO DRILL THE LARGER HOLE. THE LOCATION OF HOLE SHOULD CORRESPOND TO THE GIVEN DIMENSIONS WITHIN TOLERANCE. |
| 4. | SAND THE SIDES OF THE BLOCK UNTIL ALL DIMENSIONS ARE WITHIN TOLERANCE. |



ISOMETRIC VIEW

FOR REFERENCE ONLY
SCALE 1:2

DRAWN BY ANDREW WEIR	DATE 11/19/2019	STOCK VENDOR INFO: HOME DEPOT MODEL # 0133166	
APPROVALS:		CARELESS BRONCOS	
AU EMAIL	SIGNATURE	MATERIAL: Pine	
		TITLE/DESC: RELEASE CONNECTING SUPPORT	
		FILE NAME: Release support	
		DWG. #: P-041	REV #: A
		SCALE: 1:1	SIZE B
			SHEET 1 OF 1

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
ANGLES ARE IN DEGREES
3rd Angle Projection

TOLERANCES:
ANGULAR $\pm 1^\circ$
FRACTIONAL $\pm 1/8"$
ONE PLACE DECIMAL $\pm 0.1"$
TWO PLACE DECIMAL $\pm 0.13"$
THREE PLACE DECIMAL $\pm 0.125"$

4

3

2

1