



SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	2 IN. X 4 IN. X 16 FT. SPRUCE PINE FIR LUMBER
1.	USE A CIRCULAR SAW TO CUT THE A BLOCK WITH LENGTH APPROXIMATELY EQUAL TO DIMENSIONS GIVEN. DIMENSIONS FOR WIDTH AND HEIGHT ARE EQUAL TO PURCHASED DIMENSIONS.
2.	USE A DRILL WITH 1/8 IN. TO DRILL THE SMALL HOLES ON BOTH SIDES OF THE BLOCK. THE LOCATION OF THE HOLES SHOULD FALL WITHIN TOLERANCES GIVEN. THE DEPTH OF THE HOLES ONLY HAVE TO FALL WITHIN 1 IN. OF TOLERANCE.
3.	SAND THE SIDES OF THE BLOCK UNTIL ALL TOLERANCES FALL WITHIN GIVEN TOLERANCES.



ISOMETRIC VIEW  
FOR REFERENCE ONLY  
SCALE 1:8



DRAWN BY ANDREW WEIR	DATE 11/21/2019	STOCK VENDOR INFO: HOME DEPOT MODEL # 0133166	
APPROVALS:		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGLES ARE IN DEGREES 3rd Angle Projection	
AU EMAIL	SINGNATURE	CARELESS BRONCOS	
		MATERIAL: Pine	
		TITLE/DESC: RAMP CONNECTING SUPPORT	
		FILE NAME: base support	
		DWG. #: P-035	REV #: A
		SCALE: 1:3	SHEET 1 OF 1
		SIZE B	