




SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	BC SANDED PINE PLYWOOD 23/32 IN. X 4 FT. X 8 FT.
1.	USE CIRCULAR SAW TO CUT A BLOCK WITH APPROXIMATE HEIGHT AND WEIGHT SHOWN. WIDTH OF BLOCK WILL COME FROM PURCHASED PRODUCT.
2.	USE A DRILL WITH 1/8 IN. BIT SIZE TO DRILL HOLES IN APPROPRIATE LOCATIONS. LOCATIONS SHOULD FALL WITHIN TOLERANCES.
3.	USE SAND PAPER TO SAND EDGES OF BLOCK UNTIL ALL DIMENSIONS ARE WITHIN TOLERANCE.



ISOMETRIC VIEW
FOR REFERENCE ONLY
SCALE 1:2



DRAWN BY ANDREW WEIR	DATE 11/21/2019	STOCK VENDOR INFO: HOME DEPOT # 201428	
APPROVALS:		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGLES ARE IN DEGREES 3rd Angle Projection	
AU EMAIL	SINGNATURE	CARELESS BRONCOS	
		MATERIAL: Pine	
		TITLE/DESC: Position Marker	
		FILE NAME: Position Marker	
		DWG. #: P-038	REV #: A
		SCALE: 1:1	SIZE B SHEET 1 OF 1
		TOLERANCES: ANGULAR ± 1° FRACTIONAL ± 1/8" ONE PLACE DECIMAL ± 0.1" TWO PLACE DECIMAL ± 0.13" THREE PLACE DECIMAL ± 0.125"	