


4

3

2

1


SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	SEE BOM
1.	ATTACH ITEM 6 TO ITEM 4 USING ITEM 5. SCREWS SHOULD BE INSERTED INTO THE PILOT HOLES ON THE APPROPRIATE SIDE OF THE WOOD AS INDICATED BY THE DRAWING.
2.	ATTACH THE FIVE QUANTITIES OF ITEM 1 TO THE OTHER SIDE OF ITEM TWO USING ITEM 5. SCREWS SHOULD BE INSERTED INTO THE CORRECT PILOT HOLES AS INDICATED BY THE DRAWING.
3.	ATTACH ITEM 2 TO THE FIVE QUANTITIES OF ITEM 1 USING ITEM 5. SCREWS SHOULD BE INSERTED INTO THE CORRECT PILOT HOLES AS INDICATED BY THE DRAWING.
4.	ATTACH ITEM 3 TO THE TOP OF THE TOP OF THE CREATED STRUCTURE USING ITEM 7. WARP ITEM 3 UNTIL IT IS FLUSH WITH THE TOP OF THE STRUCTURE.



ISOMETRIC VIEW
FOR REFERENCE ONLY
SCALE 1:12

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	P-035	Ramp Support	5
2	P-034	Ramp Right Side	1
3	P-036	Ramp Top	1
4	P-033	Ramp Left Side	1
5	P-037	Wood Screw No. 8 Size, 1-1/2" Long	42
6	P-038	Position Marker	1
7	-	Gorilla Glue 9oz Heavy Duty Construction Adhesive	AR

DRAWN BY Andrew Weir	DATE 12/5/2019	STOCK VENDOR INFO: SEE PARTS LIST	
APPROVALS:		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGLES ARE IN DEGREES 3rd Angle Projection	
AU EMAIL	SINGNATURE	Careless Broncos	
		MATERIAL: SEE PARTS LIST	
		TITLE/DESC: Ramp	
		FILE NAME: Ramp	
		DWG. #: A-004	REV #: A
		SCALE: 1:12	SHEET 1 OF 1
		SIZE B	



3

2

1