



4

3

2

1

SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	12 in. x 24 in. Leathergrain Aluminum Sheet in Silver
1.	Cut a strip of material from the sheet of proper dimensions with a band saw
2.	Drill the holes using a power drill
3.	Sand the edges using silicon carbide sandpaper
4.	Bend the strip, by using the procedure of heat bending, according to the given tollerances



1:1 Reference  
Just for scale

DRAWN BY Giampietro Nigro	DATE 11/18/2019	STOCK VENDOR INFO: Home Depot Model # 56030	
APPROVALS:		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGLES ARE IN DEGREES 3rd Angle Projection	
AU EMAIL	SINGNATURE	Careless Broncos	
		MATERIAL: Leathergrain Aluminum Sheet in Silver	
		TITLE/DESC: Split frame 1 Rear	
		FILE NAME: Frame1 Rear	
		DWG. #: P-001	REV #: D
		SCALE: 1:1	SHEET 2 OF 2
		SIZE B	

4

3

2

1