





SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	SELECT PINE BOARD 1in. X 6in. X 6ft.
1.	USE A CIRCULAR SAW TO CUT OUT A BOARD WITH LENGTH AND HEIGHT APPROXIMATELY EQUAL TO DIMENSIONS GIVEN.
2.	USE A BAND SAW TO CUT OUT THE INNER RECTANGLE TO CREATE THE HOOK SHAPE. THE CUT SHOULD BE DONE TO APPROXIMATE DIMENSIONS GIVEN.
3.	USE A DRILL WITH APPROPRIATE BIT SIZE TO CREATE HOLES IN THE LOCATIONS GIVEN. BIT SIZE OF .75 IN SHOULD CORRESPOND TO APPROXIMATE DIMENSION GIVEN. LOCATION OF HOLE SHOULD FALL WITHING GIVEN TOLERANCES.
4.	USE SAND PAPER TO SAND THE EDGES OF THE CREATED PART UNTIL EACH DIMENSION IS WITHIN TOLERANCE.



ISOMETRIC VIEW
FOR REFERENCE ONLY
SCALE 1:2

DRAWN BY ANDREW WEIR	DATE 11/21/2019	STOCK VENDOR INFO: HOME DEPOT MODEL #928787		
APPROVALS:		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGLES ARE IN DEGREES 3rd Angle Projection		
AU EMAIL	SINGNATURE	CARELESS BRONCOS		
		MATERIAL: Pine		
		TITLE/DESC: RELEASE HOOK		
		FILE NAME: RELEASE HOOK		
		DWG. #: P-042	REV #: C	
		SCALE: 1:2	SIZE B	SHEET 1 OF 1