




4

3

2

1

SAMPLE FABRICATION/ASSEMBLY PROCESS	
STOCK DESC/DIMS	12 in. x 24 in. Leathergrain Aluminum Sheet in Silver
1.	Cut a strip of material from the sheet of proper dimensions with a band saw
2.	Drill the holes using a power drill
3.	Sand the edges using silicon carbide sandpaper
4.	Bend the strip, by using the procedure of heat bending, according to the given tollerances



1:2 Refence  
Just for scale

DRAWN BY Giampietro Nigro	DATE 12/6/2019	STOCK VENDOR INFO: Home Depot Model # 56030	
APPROVALS:		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES ANGLES ARE IN DEGREES 3rd Angle Projection	
AU EMAIL	SINGNATURE	Careless Broncos	
		MATERIAL: Leathergrain Aluminum Sheet in Silver	
		TITLE/DESC: Split frame 2	
		FILE NAME:	Frame2
		DWG. #:	P-030
		REV #:	A
		SCALE: 1:2	SHEET 2 OF 2

3

2

1