



Customer : ETD
Type : A380
Rev. Date : Jan 01, 2016

Manual : TSM
Selected applicability : ALL

36-22-71-991-00100-00-A / SHEET 2/2 - Engine 1 Pylon
Loop A Location Zone and Access Panel "Open Circuit"

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				1.56	5.12	62				
054				3.60	11.81	62				
055				5.64	18.50	62				
056				1.72	5.64	4089				
057				3.76	12.34	4089				
058				5.80	19.03	4089				
059				7.84	25.72	4089				
060				9.88	32.41	4089				
061				11.91	39.07	4089				
062				13.95	45.77	4089				
063				15.99	52.46	4089				
064				18.03	59.15	4089				
065				20.07	65.85	4089				
066				22.10	72.51	4089				
067				24.14	79.20	4089				
068				26.18	85.89	4089				
069				28.22	92.59	4089				
070				30.26	99.28	4089				
071				32.30	105.97	4089				
072				34.33	112.63	4089				
073				1.97	6.46	924				
074				4.01	13.16	924				
075				6.05	19.85	924				
076				8.09	26.54	924				
077				10.12	33.20	924				
078				12.16	39.90	924				
079				14.20	46.59	924				
080				16.24	53.28	924				
081				18.28	59.97	924				
082				20.31	66.63	924				
083				22.35	73.33	924				
084				24.39	80.02	924				
085				26.43	86.71	924				
086				28.47	93.41	924				
087				2.04	6.69	7592				
088				4.08	13.39	7592				
089				6.12	20.08	7592				
090				8.16	26.77	7592				
091				10.20	33.46	7592				
092				12.24	40.16	7592				
093				14.27	46.82	7592				
094				2.09	6.86	22				
095				4.13	13.55	22				
096				6.17	20.24	22				
097				8.21	26.94	22				
098				10.24	33.60	22				
099				1.53	5.02	14				
100				3.57	11.71	14				

NOTE:

THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN). ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362271_2_BTAA_02_00

Figure 36-22-71-991-00100-A- / SHEET 2/2 - Engine 1 Pylon
Loop A Location Zone and Access Panel "Open Circuit"

** ON A/C ALL