



Notes:
add stm32 pin to monitor sync out
Connect up convtroll voltage to OXC0
Check instrumnets input levels required
Add TXCO or XO option
Add 3rd 10 Mhz Sin output
Sort out connectors (JST-ph ??)
Split into 3 board sections
Add mount wholes
add tool holes
Board interconnects
redac decoupling caps on dual supply op amps
LM393 is too slow

