





## Power Connections





DSI Pins  
(Not used)




Button inputs for Joysticks or second L/R buttons?



USB Xinput Device



## Camera




## HDMI Out


might ditch both this and the camera connector

## Audio


update this to use the Retro CM3 Audio circuit




## USB Hub





## Display




## Touchscreen Driver



Replace this with a single pot? (no soldered jumpers)



I have two different USB hub ICs. I'm not sure which one I want to use yet. The one on the right has more components, but isn't as fast.



Sheet: /		
File: Pi-Game-Console.sch		
<b>Title:</b>		
Size: A2	Date:	<b>Rev:</b>
KiCad E.D.A. kicad (5.1.5)-2		Id: 1/2

