


VIN+ = Positive input to the device.
high-side: connect to power supply side of sense resistor



SSR output over current/over voltage


PA5

R8 330R

GND

TLP172GM U1

ScrewTerminal J6



Rev: 1
Id: 1/1